

Contents

Foreword	(iii)
Preface	(v)
1. Chapter 1 : Introduction	1
2. Chapter 2 : Design Parameters	
2.1 Span of River Crossing	2
2.2 Climatic Conditions	2
2.2.1 Wind	2
2.2.2 Reference Wind Speed (VR)	4
2.2.3 Design Wind Speed, (Vd)	4
2.2.4 Terrain Roughness Coefficient (K_2)	4
2.2.5 Design Wind Pressure (Pd)	4
2.2.6 Wind Loads	4
(A) Wind Load on Tower	4
(B) Wind Load on Conductor and Groundwire	5
(C) Wind Load on Insulators	7
2.3 Temperature	7
2.4 Isokeraunic Level	10
2.4.1 Lightning Consideration for Tower Design	10
2.5 Seismic Intensity	10
2.6 Ice Formation	10
3. Chapter 3 : Clearances	
3.1 Live Line – Metal Clearances - Table 7	11
3.2 Minimum Clearances above Ground and River	12
3.3 Clearance between Conductor and Groundwire	12
3.3.1 Clearance between Conductor and Groundwire at Tower – Shield Angle	12
3.3.2 Clearance between Conductor and Groundwire at Mid-Span (Mid-Span Separation)	12
3.4 Spacing between Conductors/Phase-to-Phase Clearance	13
4. Chapter 4 : Transmission Line Components	
4.1 Normal Practices	14
4.2 Power Conductor	14
4.3 Insulator Strings	15
4.4 Earthwire	16
5. Chapter 5 : Span of River Crossing – Sag Tension Calculation	
5.1 River Crossing Span/Design Span	17
5.2 Anchor Span	17
5.3 Wind Span	17
5.4 Weight Span	17

5.5	Ruling Span/Equivalent Span	17
5.6	Sag Tension Calculation	17
6.	Chapter 6 : Philosophy of Design	
6.1	Return Period	18
6.2	Type of Tower	18
6.3	Wind on Tower	18
6.4	Deviation Angle	18
7.	Chapter 7 : Requirement of Brokenwire for River Crossing Tower (Suspension Type)	
7.1	Single Circuit Tower	19
7.2	Double and Multiple Circuit Tower	19
7.3	Broken Limb Condition for 'V' Insulator String	19
8.	Chapter 8 : Loading	
8.1	Requirement of Loads	20
8.2	Nature of Loads	20
	8.2.1 Transverse Loads (T)	20
	8.2.2 Vertical Loads (V)	20
	8.2.3 Longitudinal Loads (L)	20
8.3	Loading Criteria	20
8.4	Angle of Incidence of Wind	20
8.5	Transverse Loads (TR) – Reliability Condition	21
	8.5.1 Wind Load on Conductor/Groundwire	21
	8.5.2 Wind Load on Insulator String	22
	8.5.3 Wind Load on Tower	22
	8.5.4 Transverse Load from Mechanical Tension of Conductor and Groundwire due to Line Deviation	22
	8.5.5 Total Transverse Load (TR) under Reliability Condition	23
8.6	Transverse Load (TS) – Security Condition	23
8.7	Transverse Load (TM) during Construction and Maintenance – Safety Condition	23
	8.7.1 Normal Condition	23
	8.7.2 Brokenwire Condition	24
8.8	Vertical Loads (VR) – Reliability Condition	24
8.9	Vertical Loads (VS) – Security Condition	24
8.10	Vertical Loads during Construction and Maintenance (VM) – Safety Condition	24
8.11	Longitudinal Loads (LR) – Reliability Condition	25
8.12	Longitudinal Load (LS) – Security Condition	25
8.13	Longitudinal Loads during Construction and Maintenance (LM) – Safety Condition	25
	8.13.1 Normal Condition	25
	8.13.2 Brokenwire Condition	25
8.14	Loading Combination under Reliability, Security and Safety Conditions	25
	8.14.1 Reliability Condition (Normal Condition)	25
	8.14.2 Security Condition (Brokenwire Condition)	26
	8.14.3 Safety Condition (Construction and Maintenance)	26
8.15	Brokenwire Condition	26

9.	Chapter 9 : Special Considerations	
9.1	Truncation Facilities	27
9.2	Maximum Height of Tower	27
9.3	Use of Special Conductor	27
9.4	Steel Quality	27
9.5	Minimum Thickness of Angle Section Used	27
9.6	Bolts and Nuts	27
9.7	Slenderness Ratio	28
9.8	Redundant Member	28
9.9	Aviation Requirements	28
	9.9.1 Painting of Towers	28
	9.9.2 Span Markers	28
	9.9.3 Night Aviation Signals	29
9.10	Platforms and Ladders	29
9.11	Maintenance Fixtures	29
9.12	Foundations	29
9.13	Life Expectancy	29
	Annexure I	30
	Annexure II	31